

INSTRUCTIONS CZ CZECHMATE



1. Recoil Rod
4. Small Ring

2. Safety Pin
5. External Springs

3. Big Ring

1. Insert one of the rings inside the pistol's spring plug. FIG. 1

2. Place One External Spring on the Recoil Rod and insert the Recoil rod with the Spring to the spring plug. FIG. 2



3. Compress the Spring plug until the hole on the recoil rod appears and insert the Safety pin to temporarily secure it. FIG. 3



FIG. 4



4. Now the Recoil System is ready for installation. FIG. 4

5. To install-remove the DPM Recoil System on the pistol frame, follow the same procedure like the factory rod. FIG. 5



FIG. 5

For any Questions about the Installation or Operating instructions:
service@dpmssystems.com | www.dpmssystems.com