DPM RECOIL SYSTEM-SIG SAUER P365 INSTALLATION INSTRUCTIONS

The DPM Recoil Reduction System includes three different in length External Springs which are responsible not only for the force (slide on the battery) but also for the total force of the system. (Fig. 1)



1. ATTENTION: Always install the open coil of the springs on the recoil rod flange. (Fig. 2)



2. **ATTENTION:** Always install the closed coil of the springs in the spring house of the slide. (Fig. 3)



3. Finally Push the Recoil Rod forward (Fig. 4) and seat it in the correct position on the pistol's barrel (Fig. 5).





4. Ensure that the DPM system is placed in the correct way, reassemble the slide on the frame and rack the slide several times to ensure that the DPM Recoil system functions unrestricted.

For any questions about the installation or operating instructions: service@dpmsystems.com | www.dpmsystems.com