


DPM RECOIL ROD SYSTEM

FN Browning Hi-Power


INSTALLATION INSTRUCTIONS

The DPM Recoil Rod System includes one DPM Buffer Tube, three different in length buffer springs (small) & three different in length external springs. (Fig. 1)

ATTENTION: The factory recoil rod is not included.



Step 1. On the factory recoil rod insert one of the DPM Buffer Springs Soft, Medium or Hard. Then insert the DPM Tube and after this insert one of the External Springs Soft, Medium or Hard. (Fig. 2&3)



Step 2. Ensure that the DPM system is placed in the correct way, reassemble the slide on the frame and rack the slide several times to ensure that the DPM System functions unrestricted. (Fig. 4)



For any questions about the installation or operating instructions:
service@dpmssystems.com | www.dpmssystems.com

Copyright © 2020 DPM Systems Technologies Ltd.