



Remove the rail screw 1A and slide the head of the grip to the rail. If it is tight to slide, unscrew one-two turns only, the front screw 1B (FIG 1).



Slide the head of the grip to the position you wish and insert the rail screw (FIG 2 & FIG 3).



First tight the front screw (FIG 4), then tight the rail screw. (FIG 5)



Use always the included cross-head tool (S2 PH2) or a proper flat-head screwdriver (CR/V6).

For detailed instructions and usage suggestions visit:

Website: www.dpmssystems.com

YouTube: www.youtube.com/user/dpmrecoil/videos

Copyright © 2021 DPM Systems Technologies Ltd.

DPM Systems Technologies Ltd.

M. Geroulanou 116, Argiroupolis, ZIP 164 52, Athens, Greece

E-mail: service@dpmssystems.com | www.dpmssystems.com