SPECIAL INSTALLATION INSTRUCTIONS AR 9mm BUFFER



ASSEMBLING-DISASSEMBLING TOOL

Use always the Tool in the process of assembling and disassembling of the DPM Buffer System (Fig. 1, 2).


This Tool keep the Axel 1 in higher position so it makes easier the compression of the Rubber Head and the placement of the Stopper and the Safety Pin.





Follow the **General INSTALLATION INSTRUCTIONS** to exchange the Absorbing Spring or the counterweight. **ATTENTION:** You have to remove this Tool when you install the DPM Buffer System in the Rifle (Fig. 3, 4).





For questions contact the Dealer who supplied you this product. or contact us: service@dpmsystems.com
Video instructions: www.dpmsystems.com/faqs