

FOR GLOCK GEN 5 17-22-31-34-35-37 CAPTURED VERSION -ADJUSTABLE-



WARNING



Please Read and Fully Understand the Included Installation Instructions. Always wear protective glasses during installation.

Syste ecoil Reduction

DPM Systems Technologies Ltd.

Improvemen irearms Recoil

INSTALLATION INSTRUCTIONS GLOGK GEN5 CAPTURED WITH SELF LOCK WASHERS/SPACERS



No 1. Washer soft buffer for soft loads and 9mm No 2. Washer medium buffer for 9mm factory & +P No 3. Washer hard buffer for 40S&W & 10 Auto & +P *Feel free to make any possible combination with your ammunition

1. Remove the Factory Guide Rod and place one of the washers to the slide hole (Fig. 1, 2).



2a. Ensure that the washer is placed correctly and protrudes about 1mm from the slide (Fig. 2a).



3. Place the front side of the guide rod in the washer and compress from the back to lock it on the barrel position (Fig. 3)



Assemble the pistol and rack the slide a few times to check fon any unseen interferences and to ensure that the DPM Recoil System operates unrestricted.

4. To remove the washer use the recoil rod and push the washer to come out from the slide hole (Fig. 4a,b).





The new, innovative DPM washer/spacer, aside from the adjustability of the system's total force, ensures that the system it will stay in position, making the installation much easier.



Visit the product's page to watch video instructions. For any questions about the installation or operating instructions: info@dpmsystems.com | www.dpmsystems.com

The World's Only Progressive, Patented, Multi Spring Recoil Reduction System

YOUR MARKSMANSHIP DEPENDS ON THIS! Overall Advantages

- Better double-tap concentration
- Significant recoil reduction
- Slide and frame protection
- Improved firing speed
- Elimination of jams
- No modification required







DPM Systems Technologies Ltd.

info@dpmsystems.com | www.dpmsystems.com

Copyright © 2025 DPM Systems Technologies Ltd.